

To Set Date & Time on FD410



The image shows a First Data FD 410 uC terminal. The screen displays the date and time as 06/12/2012 11:06. Below this, it prompts the user to "Swipe card or select transaction" and provides a grid of transaction options: Credit, Debit, EBT, Gift, Check, and Loyalty. The keypad below the screen has a circled '0' on the bottom row, which is used to access the date and time settings.

Set Date and Time
Use this procedure to manually reset the terminal's date and time.

Press **0**.



Set Date and Time

Use this procedure to manually reset the terminal's date and time.

Touch **DATE AND TIME**.



Set Date and Time

Use this procedure to manually reset the terminal's date and time.

Touch **NO**.



Set Date and Time

Use this procedure to manually reset the terminal's date and time.

Enter the new time using the number keys and press **ENTER**.



Set Date and Time

Use this procedure to manually reset the terminal's date and time.

Enter the new date using the number keys and press **ENTER**.



Set Date and Time

Use this procedure to manually reset the terminal's date and time.

Touch **YES**.



Set Date and Time

Use this procedure to manually reset the terminal's date and time.

Press **CLEAR** to exit.